

Philips
CD Soundmachine

USB playback

AZ1837



Enjoy your music wherever you go

with USB Direct playback

Handy lifestyle design, enjoy music from different sources : USB direct, MP3-CD, radio

Enjoy your music from different sources

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- FM/MW stereo tuner

Easy to use

- CD shuffle/program/repeat
- 20-track CD programmable

PHILIPS
sense and simplicity

Highlights

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

MP3 Link for portable music



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

CD shuffle/program/repeat



The "Shuffle/Program/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle", "Program" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- USB Direct Modes: Fast Backward/Fast Forward, Previous/Next, Program Play, Shuffle

Connectivity

- USB: USB host
- 3.5mm stereo line in

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

Sound

- Output power (RMS): 2X1W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Convenience

- Display Type: LCD

Accessories

- Included accessories: 3.5mm stereo line in cable, AC Power Cord, User Manual, Warranty certificate

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Dimensions

- Packaging dimensions (W x H x D): 371 x 262 x 139 mm
- Product dimensions (W x H x D): 341 x 122 x 236 mm
- Weight: 1.8 kg
- Weight incl. Packaging: 2.4 kg



Issue date 2010-07-31

Version: 1.0.4

12 NC: 8670 000 57328
EAN: 87 12581 51107 4

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com